



LAWRENCE
LIVERMORE
NATIONAL
LABORATORY

Laser Performance Operations Model (LPOM): A Tool to Automate the Setup and Diagnosis of the National Ignition Facility

M. Shaw, R. House, C. Haynam, W. Williams

July 30, 2005

SPIE Optics & Photonics Conference, 2005
San Diego, CA, United States
July 31, 2005 through August 4, 2005

Disclaimer

This document was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor the University of California nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or the University of California. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or the University of California, and shall not be used for advertising or product endorsement purposes.

Laser Performance Operations Model (LPOM): A Tool to Automate the Setup and Diagnosis of the National Ignition Facility



August 3, 2005



**Michael Shaw, Ronald House, Chris Haynam,
Wade Williams**

**Lawrence Livermore National Laboratory,
Livermore, CA 94550, USA**

This work was performed under the auspices of the U.S. Department of Energy by the University of California, Lawrence Livermore National Laboratory under Contract No. W-7405-Eng-48.

ABSTRACT



The National Ignition Facility

The National Ignition Facility (NIF), currently under construction at the University of California's Lawrence Livermore National Laboratory (LLNL) is a stadium-sized facility containing a 192-beam, 1.8 MJ, 500-TW, 351-nm laser system together with a 10-m diameter target chamber with room for nearly 100 experimental diagnostics. When completed, NIF will be the world's largest laser experimental system, providing a national center to study inertial confinement fusion and the physics of matter at extreme energy densities and pressures. The first four beamlines (a quad) have recently been commissioned, and operations on the first bundle (units of eight beamlines) will begin in Summer 2005. A computational system, the Laser Performance Operations Model (LPOM) has been developed and deployed to automate the laser setup process, and accurately predict laser energetics. For each shot on NIF, the LPOM determines the characteristics of the injection laser system required to achieve the desired main laser output, provides parameter checking for equipment protection, determines the required diagnostic setup, and supplies post-shot data analysis and reporting.



The National Ignition Facility


BACKGROUND SECTION

Description of the National Ignition Facility



The National Ignition Facility

- NIF is a stadium-sized facility containing a 192-beam, 1.8-MJ, 500-TW, 351-nm laser system
 - The beams are grouped in 48, 4-beam quads, which share a common injection laser system
- The target is encased in a 10-meter diameter target chamber with room for nearly 100 experimental diagnostics



NIF Operations Requires Detailed Laser Energetics Models



The National Ignition Facility

- NIF operations require precisely specified energy waveforms from 192 beams for a variety of pulse lengths and temporal shapes
- NIF laser pulses are amplified from 1 nJ up to 20 kJ
 - Injected pulses undergo significant pulse distortion due to gain saturation
 -
- The system must accurately control 192 beamlines and 48 injection laser systems that have variations in:
 - Beamline-to-beamline optical transmission;
 - Beamline-to-beamline amplifier slab configurations (gain);
 - Quad-to-quad amplifier pumping
- NIF to be operated at very high energy and power, but with low risk of optical damage
- The Laser Performance Operations Model (LPOM) has been developed to provide this functionality for NIF

FUNCTIONAL REQUIREMENTS

Laser Performance Operations Model (LPOM) Functional Requirements



The National Ignition Facility


- **Automate shot setup**
 - **Specifies injection laser energy and temporal shape;**
 - **Predicts laser fluence at all laser diagnostic locations;**
 - **Feedback data to update the laser model**

- **Assists in equipment protection**
 - **Assures that the predicted fluences and intensities lie within operational limits**
 - **Verifies that injection system is properly configured prior to main laser shot**

- **Post-shot analysis and archive tool**
 - **Post shot data reports and analysis tools**
 - **Web browser access to processed data provide easy access before, during and after shot operations**

LPOM supports shot planning, operations, shot director and NIF users

LPOM consists of several interacting, functional modules






The National Ignition Facility

SHOT SETUP

LPOM automates shot setup and uses post shot analysis to maintain an accurate model of NIF







The National Ignition Facility



A comprehensive beamline model is essential to accurately describe how NIF works



The National Ignition Facility



LPOM turns goals into the required shot settings

- LPOM turns high level shot goals into specific shot settings
- Settings communicated to other NIF laser subsystems through

Shot Setup / Shot Verification / Optimize Model / Shot History

Experiment ID: FIT_PERF_TEST_4_mod

Goals Setup Data Case Data Requested Energy Damage Delta-B Filamentation Settings

Goals Options Damage Limits Shot Settings Model Summary Equipment Protection Pulse Shapes Debug


Quad Total E (kJ)
Q31B 78.7122

Predicted Energetics

	Regen (mJ)	ISP (J)	OSP-DB (kJ)	RMDA (kJ)	3 ω TCC (kJ)	1 ω PDS (kJ)	3 ω PDS (kJ)	
Q31B	1.83141	1.26225	19.9067	19.9067	0.0	0.0	0.0	B315
			19.9107	0.0	0.0	18.9151	0.0	B316
			19.9478	19.9478	0.0	0.0	0.0	B317
			19.9426	19.9426	0.0	0.0	0.0	B318

Attenuator Settings and Split Fractions

power out (mW)




nanosecs

Pulse Length (ns) 23.0
Post Pulse (ns) 0.0

MOR

Input sensor

PAM



19.26% B316
28.42% B318
20.24% B315
32.08% B317

Attenuators		PABTS	
Input	Output		
T=23.6%	T=90.0%	1	52.3%
		2	61.3%
		3	59.6%

PAM Gain 765 Calculated Date Mon Aug 04 15:53:07 PDT 2003 Quad IPS Report Near Field

Load Goals Calculate Settings Accept Settings LPOM Status: Ready



The National Ignition Facility

EQUIPMENT PROTECTION

LPOM plays a critical role in the protection of the NIF laser



LPOM has three roles in the NIF equipment protection process

- **Prior to shot:**
 - **Compares predicted fluences and intensities to optical damage limits**

- **During the shot cycle:**
 - **Verifies injection laser system produces energy, power and spatial distribution required for a full system shot**
 - **Automatically alerts Shot Director with status of system**

- **After main laser shot:**
 - **Compares measured values to predicted, providing**
 - **A quick determination the success of a shot; and**
 - **Validation of the LPOM model**


LPOM provides expert groups detailed pre-shot analysis of equipment risk of proposed shots

- Results of Shot Setup calculations provide information concerning the risk to critical optical component throughout the NIF system
- Due to level of confidence in LPOM calculations, no shots that exceed damage limits are allowed to be scheduled

Q31B		Maximum Optic Name		Beamline		Legend:					
✓	Optics Damage (Fluence)	99.34%	PM1	B318	✓	safe					
✓	Delta-B	1.34%	Debris Shield	B318	⊘	above threshold					
✓	Filamentation (Intensity)	29.46%	SF4	B316	⚠	above conditioning fluence					
Optic Name	Max Flu	Ave Flu	Damage Flu	Damage Ratio	Max Delta-B	Beam Area	Tau Eq	Max Int	Filament Ratio	frac over damage	Loc
Debris Shield	15.86	6.26	4.00	3.97	1.34	781.84	2.27	3.59	0.18	0.98	B318
Tripler	14.85	5.85	4.00	3.71	0.54	853.11	2.27	3.35	0.17	0.97	B318
BSG	15.83	6.24	4.00	3.96	1.19	799.93	2.27	3.58	0.18	0.98	B318
FFL	14.84	5.85	4.00	3.71	1.05	853.11	2.27	3.35	0.17	0.97	B318
SHG	21.51	8.64	41.67	0.52	0.54	859.71	2.97	5.41	0.27	0.00	B318
Pol on refl	7.94	6.07	9.84	0.81	0.43	847.61	2.49	2.47	0.12	0.00	B315
Pol on refl	8.23	6.02	9.79	0.84	0.43	853.59	2.45	2.68	0.13	0.00	B316
Pol on refl	8.26	5.77	9.83	0.84	0.41	873.52	2.48	2.62	0.13	0.00	B317
Pol on refl	8.07	5.91	9.75	0.83	0.42	863.47	2.43	2.72	0.14	0.00	B318
LM3	7.85	6.07	9.83	0.80	0.43	847.70	2.49	2.45	0.12	0.00	B315
LM3	7.72	6.01	9.79	0.79	0.43	854.48	2.45	2.48	0.12	0.00	B316
LM3	8.08	5.76	9.82	0.82	0.41	873.81	2.48	2.57	0.13	0.00	B317
LM3	7.82	5.90	9.74	0.80	0.42	864.22	2.42	2.65	0.13	0.00	B318
LM2	0.11	0.06	8.94	0.01	0.00	911.76	1.89	0.05	0.00	0.00	B315
LM2	0.11	0.06	8.94	0.01	0.00	916.93	1.89	0.05	0.00	0.00	B316
LM2	0.12	0.07	8.94	0.01	0.00	941.53	1.90	0.05	0.00	0.00	B317
LM2	0.11	0.06	8.94	0.01	0.00	927.49	1.89	0.05	0.00	0.00	B318
Inject Mirror	0.17	0.06	21.72	0.01	0.00	2.48	1.84	0.08	0.00	0.00	B315
Inject Mirror	0.16	0.06	21.72	0.01	0.00	2.46	1.84	0.07	0.00	0.00	B316
Inject Mirror	0.25	0.09	21.72	0.01	0.00	2.46	1.84	0.12	0.01	0.00	B317
Inject Mirror	0.20	0.07	21.72	0.01	0.00	2.49	1.84	0.09	0.00	0.00	B318
PM7	20.74	8.64	22.88	0.91	0.32	859.83	2.59	5.19	0.26	0.00	B318
PM1	17.45	9.19	17.57	0.99	0.26	852.87	2.80	4.67	0.23	0.00	B318
TCVW	21.51	8.64	37.36	0.58	0.54	859.71	2.84	5.41	0.27	0.00	B318
SF1(pass4)	8.14	6.09	32.96	0.25	0.96	844.18	2.43	2.63	0.13	0.00	B315
SF1(pass4)	8.65	6.01	32.84	0.26	0.94	851.31	2.40	2.72	0.14	0.00	B316
SF1(pass4)	9.13	5.75	32.81	0.28	0.93	872.66	2.39	2.73	0.14	0.00	B317
SF1(pass4)	9.65	5.92	32.80	0.29	0.93	857.51	2.39	2.89	0.14	0.00	B318
SF3	12.11	9.39	37.80	0.32	1.04	848.54	2.93	3.37	0.17	0.00	B315
SF3	13.95	9.28	37.77	0.37	1.03	853.08	2.92	3.80	0.19	0.00	B316
SF3	13.39	8.87	37.46	0.36	0.99	873.36	2.86	3.52	0.18	0.00	B317
SF3	14.31	9.08	37.38	0.38	1.01	865.61	2.85	3.58	0.18	0.00	B318
SF4	17.54	9.39	38.43	0.46	0.20	846.19	3.05	5.45	0.27	0.00	B315
SF4	20.64	9.38	37.55	0.55	0.20	844.97	2.88	5.89	0.29	0.00	B316

LPOM verifies laser system is configured for main system shot

- Prior to a full system shot, a shot using only the injection laser system is conducted
- LPOM determines if system is ready for full energy by comparing measurements to predictions
 - System readiness communicated to Shot Director within minutes of shot, along with recommended adjustments

 **LPOM**
Laser Performance Operations Model

Shot Verification Status

Shot ID: **N050701-001-006**

Exp Id: **ML_Rod_Shot_OQ_P2a_S03a**

PI: **haynam1**


Bay 1						Bay 2					
Cluster 1						Cluster 3					
Bu11	Bu12	Bu13	Bu14	Bu15	Bu16	Bu31	Bu32	Bu33	Bu34	Bu35	Bu36
✓ Q11T	✓ Q12T	✓ Q13T	✓ Q14T	✓ Q15T	✓ Q16T	✓ Q31T	✓ Q32T	✓ Q33T	✓ Q34T	✓ Q35T	✓ Q36T
✓ Q11B	✓ Q12B	✓ Q13B	✓ Q14B	✓ Q15B	✓ Q16B	✓ Q31B	✓ Q32B	✓ Q33B	✓ Q34B	✓ Q35B	✓ Q36B
Cluster 2						Cluster 4					
Bu21	Bu22	Bu23	Bu24	Bu25	Bu26	Bu41	Bu42	Bu43	Bu44	Bu45	Bu46
✓ Q21T	✓ Q22T	✓ Q23T	✓ Q24T	✓ Q25T	✓ Q26T	✓ Q41T	✓ Q42T	✓ Q43T	✓ Q44T	✓ Q45T	✓ Q46T
✓ Q21B	✓ Q22B	✓ Q23B	✓ Q24B	✓ Q25B	✓ Q26B	✓ Q41B	✓ Q42B	✓ Q43B	✓ Q44B	✓ Q45B	✓ Q46B

LPOM Recommended changes:
Low energy in Q31T, increase regen energy to 9.015 (from 8.12)
Low energy in Q31B, increase regen energy to 8.964 (from 8.21)

Legend:
✓ Pass Ready for system shot. Quad passed rod shot verification checks.
✓ N/A Ready for system shot. Quad not participating in shot.
✓ Caution Quad passed, but another rodshot may be recommended
⊘ Fail Not ready for system shot
⊘ Pending Quad not yet verified

Home LPOM Status


Select Shot Id or Exp Id:



DATA ANALYSIS AND REPORTING

LPOM presents shot data in a drill down fashion

- Web-based data reporting tool provides shot data, at various levels of complexity, to NIF community
- Drill-down navigated downward from Shot Status → Shot Metrics → Detailed reports for each participating quad
- Parallel computational design assures scalability to full NIF


LPOM
Laser Performance Operations Model

Shot Verification Status

Shot ID: **N050701-001-006**
 Exp Id: **ML_Rod_Shot_OQ_P2a_S03a**
 Pl: **haynam1**

Bay 1						Bay 2					
Cluster 1						Cluster 3					
Bu11	Bu12	Bu13	Bu14	Bu15	Bu16	Bu31	Bu32	Bu33	Bu34	Bu35	Bu36
✓ Q11T	✓ Q12T	✓ Q13T	✓ Q14T	✓ Q15T	✓ Q16T	✓ Q31T	✓ Q32T	✓ Q33T	✓ Q34T	✓ Q35T	✓ Q36T
✓ Q11B	✓ Q12B	✓ Q13B	✓ Q14B	✓ Q15B	✓ Q16B	✓ Q31B	✓ Q32B	✓ Q33B	✓ Q34B	✓ Q35B	✓ Q36B
Cluster 2						Cluster 4					
Bu21	Bu22	Bu23	Bu24	Bu25	Bu26	Bu41	Bu42	Bu43	Bu44	Bu45	Bu46
✓ Q21T	✓ Q22T	✓ Q23T	✓ Q24T	✓ Q25T	✓ Q26T	✓ Q41T	✓ Q42T	✓ Q43T	✓ Q44T	✓ Q45T	✓ Q46T
✓ Q21B	✓ Q22B	✓ Q23B	✓ Q24B	✓ Q25B	✓ Q26B	✓ Q41B	✓ Q42B	✓ Q43B	✓ Q44B	✓ Q45B	✓ Q46B

LPOM Recommended changes:
 Low energy in Q31T, increase regen energy to 9.015 (from 8.12)
 Low energy in Q31B, increase regen energy to 8.964 (from 8.21)

Legend:


✓ Pass	Ready for system shot. Quad passed rod shot verification checks.
✓ N/A	Ready for system shot. Quad not participating in shot.
✓ Caution	Quad passed, but another rodshot may be recommended
✗ Fail	Not ready for system shot
⏸ Pending	Quad not yet verified

System shot data reporting is accessible immediately to operations and users



The National Ignition Facility

- Second level is a detailed comparison of predicted and measured data




More detailed analysis results can be viewed from results page



The National Ignition Facility

- Hyperlinks from results page allow users to drill down to more detailed analysis reports
- Processed predicted and measured data can be downloaded




RESULTS

LPOM has been able to accurately predict energies for each beamline for over a wide operating range



The National Ignition Facility



Bundle 31

311	312
313	314
315	316
317	318


- LPOM calibrated with two low energy shots at beginning of campaign
- Energy balance (within quad) within 1-2% for all shots

LPOM accurately models gain saturation of the laser temporal pulse as it propagates



The National Ignition Facility

2010-2011 National Ignition Facility







LPOM is the backbone of meeting target irradiance requirements

LPOM has been able to accurately predict pulse shapes for a wide variety of missions



The National Ignition Facility




The observed RMS deviation of the Haan pulse is consistent with ignition requirements


LPOM has helped NIF meet its functional requirements for energy accuracy

- Power balance requires an 8% RMS on 3w output energy
 - Target campaign shows < 2% RMS of energy on target

Beam Timing Adjusted to Within 6 ps (rms)



Hydro Campaign Shot Energy Histogram



Measured timing and energy stability are consistent with ignition requirements

Summary



- **LPOM serves a role in automated shot setup, equipment protection and data analysis for NIF**
- **LPOM has been an invaluable tool in NIF laser commissioning activities**
 - **Accurately set up shot for several laser configurations, and over a wide energy range**
 - **Provide energy balance amongst the quad to within 1-2%**
 - **Produces output pulse shapes that are flat or match complicated requested shapes**
- **LPOM provides post-shot data reporting and analysis**
 - **Web-based reporting tool provides data to aid shot operations, shot planning and data analysis**
- **LPOM has been proven to be scalable and capable of operating in a fully automated fashion**