



LAWRENCE
LIVERMORE
NATIONAL
LABORATORY

Compressible gas flow through micro-capillary fill-tubes on NIF targets- modeling and experiments

S. D. Bhandarkar, T. G. Parham, J. E. Fair

February 18, 2010

19th Target Fabrication Meeting
Orlando, FL, United States
February 21, 2010 through February 26, 2010

Disclaimer

This document was prepared as an account of work sponsored by an agency of the United States government. Neither the United States government nor Lawrence Livermore National Security, LLC, nor any of their employees makes any warranty, expressed or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States government or Lawrence Livermore National Security, LLC. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States government or Lawrence Livermore National Security, LLC, and shall not be used for advertising or product endorsement purposes.




Compressible gas flow through micro-capillary fill-tubes on NIF targets- modeling and experiments

**Presentation at the
19th Target Fabrication Meeting
Feb 25th, 2010**

**Suhas Bhandarkar,
Tom Parham, Jim Fair**

NIF targets have two separate chambers (capsule/hohlraum) which are pressurized using filltubes

- Fill tubes supply gases to the two chambers – capsule and hohlraum
 - Capsule fill tube specification:
5 μ m inner dia
 - Small volume
- Fill tubes need to be about 115mm long and be flexible
- Hohlraum filltubes
 - 75 μ m ID x 150 μ m OD polyimide coated silica capillary
- Composite tube for capsule
 - Majority of length is 30 μ m ID x 150 μ m OD polyimide coated silica
 - A 5 μ m borosilicate capillary penetrates the capsule to meet the physics specs



Impedance to flow due to the small diameters of the capillaries presents a few challenges

Importance of Response Time

- Knowing the changes in pressure and composition inside the capsule or hohlraum due to temperature or pressure variations on the outside
- Sharp pressure differentials across the hohlraums can stretch or damage 500nm thick LEH windows
- Condensation of ice or debris on the inside can easily plug the capillaries
- Flow of permeated tritium out of the hohlraum


LEH window



Extending the Hagen Poiseuille equation for compressible fluid flow through a tube

Limit to:

- Low Reynolds number regime
 - Fully developed laminar flow
 - Small $\beta = R/L$ (inner radius/length)
- Small pressure drops
 - Small $\varepsilon = (P_0 - P_L)/P_0$, where P_0 & P_L are pressures at lengths 0 and L
 - In the limit, we get Hagen-Poiseuille equation
- Chose a perturbation based solution by Prud'homme et al*




Volumetric flow-rate Q :

$$Q = \frac{\pi(P_0 - P_L)R^4}{8\mu L} \left[1 - \frac{1}{2}\varepsilon - (0.02919 \kappa)\varepsilon\beta + (0.02919 \kappa)\varepsilon^2\beta + \left(\frac{2}{3} + 0.00227 \kappa^2\right)\varepsilon^2\beta^2 + \dots \right]$$

where μ is viscosity, ρ_0 is the mass density at P_0 and $\kappa = R^3\rho_0(P_0 - P_L)/L\mu$

We are interested in the gas composition and pressure in the two chambers within the target




For a chamber with volume V_c at pressure P_c and containing n_c moles:



$$\frac{dn_c}{dt} = \frac{n_c(t)}{V_c} Q(n) \quad \text{or} \quad \frac{dP_c}{dt} = \frac{P_c}{V_c} Q$$

$$\ln(P_c) + \text{Const} = \frac{Q}{V_c} t$$

Evacuation of air from target: Pressure vs time profile





A baratron with a fixed known volume can be used to generate pressure vs time data to verify model



Transition region between continuum flow and free molecular flow

Deviation at low pressure



- Continuum flow model deviates at K_n (Knudsen number) of about 0.005
 - K_n is the ratio of molecular mean free path λ to capillary diameter D
- K_n is not high enough to consider free molecular flow, instead points to transition region
- Deviation increases with increasing K_n
 - Model that accounts for transition flow using K_n


Slip flow model for flow behavior at low pressures before onset of free molecular flow

- Viscous flow uses a no slip boundary condition at the wall
 - But Navier Stokes equation ceases to be valid as $K_n > 0.01$
- For free molecular flow (neglect intermolecular collisions), incident and reflected tangential velocities are equal
- In between, invoke a slip flow model, with a small but non-zero tangential wall velocity


$$Q = \frac{\pi(\Delta P)R^4}{8\mu L} \left[1 - \frac{1}{2}\varepsilon - (0.02919\kappa)\varepsilon\beta + \dots \right] \left(1 + 4\left(\frac{2}{f_s} - 1\right) \right) \frac{\lambda}{R}$$

where f_s is the fraction of molecules impinging on the walls of the tube


Using slip flow equation



Unraveling slip flow parameters – effect of molecular diameter




- Slip flow has two parameters that need to be specified
 - f_s ,
 - hard sphere molecular diameter d , for calculation of λ



- Since air is mixed fluid, d is best specified for single component gases


- We find that f_s is constant




	d (Å)	f_s
He	2.56	0.43
Ar	4.0	0.43
Air	4.57	0.43

Some important conclusions from application of slip flow model to the capillary flow data

75 μ m, 115mm long capillary



30 μ m, 92mm long capillary





- f_s , the fraction of molecules impinging on the walls of the tube is consistently 0.43 @ RT
 - For capillaries of different dia
 - For different gases
- Slip flow model fits the data for a large range of K_n
 - from 0.005 to 18
 - at higher K_n , it approaches free molecular flow
- Data here indicates that conventional free molecular flow equation ($K_n > 1$) over-predicts the flow

Slip flow model can be used for flow at cryogenic temperatures as well

- Gases flow faster at lower temperatures as
 - Lower viscosity
 - Greater density
- Model takes into account two temperature zones
 - RT for baratron
 - Cryogenics temp for the capillary
- Viscosities from NIST for Helium can be used get an exact fit to the cryogenic data

Capillary flow of He at cryogenic T



Accounting for changing radii

- Filltubes used on NIF targets are combinations of tubes of different diameters and lengths

- For a conical tube, with inner radii R_0 and R_L and length L :


$$R_{eff} = R_0 \left[\frac{3\alpha^3}{1 + \alpha + \alpha^2} \right]^{0.25} \quad \text{where } \alpha = R_0/R_L$$

- For two tubes of inner radii R_1 and R_2 and lengths L_1 and L_2 :

Let $x = L_2/L_1$; then

$$Q = \frac{\pi(\Delta P)R_1^4}{8\mu L} \left(\frac{x}{R_2^4 + xR_1^4} \right) \left[1 - \frac{1}{2}\varepsilon - (0.02919\kappa)\varepsilon\beta + (0.02919\kappa)\varepsilon^2\beta + \dots \right]$$

Fill tubes on NIF targets are made up of multiple capillaries




Verification of the model for composite and conical tubes


**Composite fill-tube
for capsule**



Composite tube- data vs model





Model can be used to predict rate permeation of He from the polymeric films on the target





- Permeation depends on pressure
 - Pressure depends on capillary conductance
- Permeation is instantaneous compared to filling through capillary

Permeation rate of He from TMP




Extending the model to a dual chamber system allows prediction of the return line pressure



Cascading flow model

- Once the volumes are known, we can accurately model the return line pressure and therefore the conditions in the hohlraum



Summary

- **Model has been set-up and validated to predict the flow through micro-capillaries**
 - **Covers the range of pressures**
 - Continuum to molecular flow
 - **Accounts for composite capillaries connected to a series of chambers**
 - **Extends to cryogenic temperatures**
- **Data suggests that**
 - **Modified Hagen Poiseuille equation can be used for simulating viscous flow of compressible fluids for low ΔP**
 - **Slip flow extends to Knudsen numbers to at least 18**
 - **Data yields a consistent fraction of molecules reflecting specularly from the walls- 0.43 to 0.51**
- **This can be used to predict the hohlraum and capsule pressures and compositions for various external perturbations**

NIC

