

Alternate Alpha Induced Reactions for NIF Radiochemistry

D. A. Shaughnessy, K. J. Moody, L. A. Bernstein

March 2, 2010

Disclaimer

This document was prepared as an account of work sponsored by an agency of the United States government. Neither the United States government nor Lawrence Livermore National Security, LLC, nor any of their employees makes any warranty, expressed or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States government or Lawrence Livermore National Security, LLC. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States government or Lawrence Livermore National Security, LLC, and shall not be used for advertising or product endorsement purposes.

This work performed under the auspices of the U.S. Department of Energy by Lawrence Livermore National Laboratory under Contract DE-AC52-07NA27344.

Alternate Alpha Induced Reactions for NIF Radiochemistry

D.A. Shaughnessy, K.J. Moody, and L.A. Bernstein

Background:

Radiochemical analysis of NIF capsule residues has been identified as a potential diagnostic of NIF capsule performance. In particular, alpha-induced nuclear reactions that occur on tracer elements added to the NIF capsule have been shown through simulation to be a very sensitive diagnostic for mix. The short range of the alpha particles makes them representative of the hot spot where they are created through the fusion of deuterium and tritium. Reactions on elements doped into the innermost part of the capsule ablator would therefore be sensitive to material that had mixed into the hot spot. Radiochemical determinations of activated detector elements may perhaps be the only true measure of mix that occurs in a NIF capsule, particularly in cases when the capsule fails.

Requirements for Alpha Induced Reactions:

In order to measure alpha particle induced reactions in a NIF capsule, several requirements must be fulfilled. Firstly, since the alpha particle is created with 3.5 MeV of kinetic energy subsequent reactions must not have a threshold that is larger than this energy or else only upscattered alpha particles will participate in reactions with the tracer and there are far fewer ($<1/10^{1h}$) of these particles. Secondly, the cross-section for the reaction must be large enough such that there will be a measurable amount of reaction product after the shot. It has been estimated that if approximately 10⁸ atoms are created then a better than 10% measurement can be made assuming a 10⁻⁴ collection efficiency. Thirdly, the reaction product must have a half-life that is not so short that it decays before collection. A longer half-life may be possible to measure if short turnaround times are not required between NIF shots or if mass spectrometric methods can be employed. Ideally, the product would emit a characteristic radiation that would be easily visible over the background of interfering reaction products with a convenient decay rate for shorter counting times. In some cases, chemical separations may be used to purify a sample prior to nuclear counting, especially when the reaction product decay cannot be seen over a large background. In order to report absolute numbers of atoms produced during a NIF shot, the collection efficiency must be determined through measurement of a tracer coloaded with the detector element in the same part of the capsule. This means that an appropriate tracer must be available, eliminating reaction products where the corresponding tracer is too short-lived to allow it to be placed inside the capsule prior to the shot. Lastly, there must be a method for placing the detector element at the desired location in the desired well-characterized amount in the inner most part of the ablator. This list of requirements results in only a few possible alpha induced reactions that could possibly be used as a mix diagnostic in NIF point-design capsules.

 $^{18}O(\alpha,n)^{21}Ne$: Issues with chamber backgrounds may make this measurement extremely difficult. It has the largest cross section of any of the potential alpha reactions (approximately 260 mb at 3.5 MeV). Oxygen is ubiquitous throughout the capsule so that loading and subsequently assaying the ¹⁸O-content of the innermost layer of the ablator will be an issue. Enriched ¹⁸O will have to be co-loaded with ²²Ne as the tracer of the recovery fraction. A capsule that produces 200 kJ of yield results in more than $5x10^7$ atoms of ²¹Ne produced from 2.7x10¹⁵ atoms of ¹⁸O initially loaded in the ablator. In reality, the number of oxygen atoms in the capsule would probably be much higher, but they would be located throughout the capsule and not just at the ice-ablator interface. The product is a stable isotope, which means that mass spectrometric methods would have to be employed for post-shot analysis. Currently, the laboratory does not have a noble gas mass spectrometer that could be used for analysis of these samples. The ²¹Ne would be collected with the radiochemistry gas collection system already in production. However, precision measurements of the ²¹Ne produced are difficult to perform due to the large ²¹Ne background present in the target chamber. This is discussed in more detail in Ken Moody's document titled "An Evaluation of the $^{18}O(\alpha.n)^{21}$ Ne Mix Diagnostic".

 19 F(α ,n) 22 Na: The Q-value of -1.95 MeV and Coulomb barrier of E_{th}=2.0 MeV make this a possible candidate for alpha reactions. Scaling the cross section to that of the ¹⁸O reaction for the same 200 kJ shot, 1.3x10⁶ atoms of ²²Na would be produced from the same number of ¹⁹F atoms compared to ¹⁸O. The ²²Na product has a characteristic gamma ray at 1275 keV and also decays via positron emission with a half-life of 2.6 years. This longer half-life would require longer counting times before results were available. The sodium would be traced with either 15-hour ²⁴Na, making capsule fabrication more challenging, or with 27 Al (producing 24 Na in situ via the (n, α) reaction). The possibility of loading fluorine into the capsule has not yet been examined. Sodium reaction products require solid collection capability. The background may be questionable as sodium may be ubiquitous throughout the target chamber. ²²Na could also be produced in the 22 Ne(d,2n) 22 Na and 22 Ne(p,n) 22 Na reactions as well as the ²³Na(n,2n)²²Na reaction, which means that neon and sodium would have to be excluded from the target and chamber to eliminate competing background reactions. This will be extremely difficult based on current estimates of the neon background and the presence of sodium in the chamber.

 10 B(α ,n) 13 N: This reaction has a positive Q-value of 1.1 MeV and a threshold of <2.0 MeV. For a 200 kJ shot, the production of 13 N scaled to the 18 O reaction would be 1.3×10^7 atoms. It is unknown at this time if the resulting nitrogen would be present as a gas or solid (or possibly both). The possibility of placing boron in the capsule has not yet been explored. The 13 N product is a pure positron emitter with a 10-minute half-life. As we do not yet know the time constant for removing reaction products from the chamber, this short half-life cannot be excluded at this time, although it means that the chemical form of the product nitrogen must be known *a priori*. 13 N could also be made from deuteron reactions on carbon (both naturally occurring isotopes 12 C and 13 C) resulting in a potentially large background correction since carbon will be ubiquitous in the NIF chamber. If the capsule were loaded with both isotopes of Boron (10 B and 11 B) and the 13 N collected in the form of CN then it could be traced through measurement of the 11 C

from 11 B(p,n) 11 C. The resulting ratio of 13 N vs. 11 C would provide a 14 MeV neutron (i.e., yield) normalized measurement of the (α ,n) reaction. This approach is highly uncertain since the chemical composition of the 13 N collected remains unclear.

 29 Si $(\alpha,p)^{32}$ P: The Q-value for this reaction is -2.45 MeV and the Coulomb barrier is $E_{th}=2.5$ MeV, making this another possible candidate. The ^{32}P is a pure beta emitter with a 14-day half-life and an endpoint energy for decay of 1.7 MeV. Chemical separation and sample preparation will be required before a post-shot sample could be analyzed. A scaled 200 kJ shot would produce roughly 1.2x10⁷ atoms of ³²P. Phosphorous would require solid collection, with beta-emitting, 25-day ³³P used as the yield tracer (endpoint energy = 0.35 MeV) Difficulty will arise here from determining the β -background from other reaction products, such as uncollected tritium and other trace elements in the capsule such as Mg, Si, Mn, Al, Fe and Ni. ³⁰Si present in the capsule and surrounding chamber will also undergo (α,p) reactions to form ³³P. If significant ³³P is produced, it will eliminate the use of ³³P as a collection efficiency tracer. In addition, decay curve analysis over the course of several days of counting would be required to differentiate between the ³²P and ³³P beta particles, which means that this reaction would require a longer delay time between shots. Background would be produced from neutron capture reactions on naturally occurring phosphorous and (n,p) reactions on naturally occurring sulfur.

Summary:

There are several possible alpha-induced reactions that could be used as an indicator of mix in a NIF capsule. Each one has experimental challenges that can be overcome once the selection of the preferred reaction has been made. With careful design of the capsule and the surrounding environment in the NIF chamber, background from interfering nuclear reactions can be avoided resulting in a cleaner radiochemical signal. While the ²¹Ne and possibly ¹³N will be collected with gas collection, the most likely candidates for alpha-induced reactions will ultimately require the implementation of a solid collection scheme.