



LAWRENCE
LIVERMORE
NATIONAL
LABORATORY

FRMAC Interactions During a Radiological or Nuclear Event

C. T. Wong

January 31, 2011

HPS - Midyear Meeting
Charleston, SC, United States
February 6, 2011 through February 9, 2011

Disclaimer

This document was prepared as an account of work sponsored by an agency of the United States government. Neither the United States government nor Lawrence Livermore National Security, LLC, nor any of their employees makes any warranty, expressed or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States government or Lawrence Livermore National Security, LLC. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States government or Lawrence Livermore National Security, LLC, and shall not be used for advertising or product endorsement purposes.



FRMAC Interactions During A Radiological or Nuclear Event

Carolyn T. Wong

Lawrence Livermore National Laboratory
FRMAC Laboratory Analysis Working Group

FRMAC Mission Statement


During a radiological or nuclear event of national significance the Federal Radiological Emergency Monitoring and Assessment Center (FRMAC) assists federal, state, tribal, and local authorities by providing timely, high-quality predictions, measurements, analyses and assessments to promote efficient and effective emergency response for protection of the public and the environment from the consequences of such an event.

FRMAC Mission Space

- Domestic nuclear explosion
- Radiological dispersal/
exposure device incident
- Nuclear facility accident or
incident
- Nuclear weapons accident
or incident
- Transportation accident or
incident




Coordinated Radiological Emergency Response





Federal Radiological Monitoring
Assessment Center



Approximate Readiness Time After Activation – Emergency Phase

DOE

NARAC

Initial Dispersion/Predictive Plots

RAP Team

Activation

Deploy

On-Site

CMHT

Activation

Operational

CMRT Phase I

Activation

Mobilize

Deploy

On-Site

CMRT Phase II

Activation

CMRT Augmentation

Activation

Hours

0

1

2

4

12

24

Full FRMAC

State, Tribal, Local Government Response

Activation

EPA

Notification

On Scene Coordinator

Remediation

DoD, NRC, CST

Activation

Interagency


Virtual A-Team Activation

Interagency

Other Federal Agencies as appropriate will be involved at any time during the activation

National Atmospheric Release Advisory Center

- Real-time computer predictions for atmospheric transport and dispersion of radioactive materials
- Computer model calculations based on:
 - Real-time weather data
 - Terrain database
 - 3-D transport and diffusion model
- NARAC products:
 - Ground deposition plots
 - Instantaneous and time-integrated dose
 - Airborne concentrations






RAP and Radiological Search



Capabilities

Provides first response capability to Federal, State, local governments for incidents involving radiological emergencies

First Responders



- ★ 2 to 8 member team
- ★ 220 people located at 28 sites
- ★ 2-hour response time during the day
- ★ 4-hour response time at night
- ★ Approximately 400 lbs of equipment


Search for Radiological Material

- ★ Initial Assessment
- ★ Area Monitoring
- ★ Search lost/stolen radioactive material
- ★ Respond to Radioactive intel threats
- ★ 9-RAP regions

RAP may call upon other DOE assets

Radiological Triage: Radiological Analyses for First Responders

- The DOE Triage System provides rapid scientific evaluation to any responder
- Provides reach-back capability to tap into National Laboratory gamma spectroscopy scientists





Aerial Measuring System



AMS

Capabilities

Provides aviation-based equipment to survey large areas in response to radiological emergencies


Fixed-Wing Aircraft

- ♦ All-weather operation
- ♦ Rapid residual fallout pattern
- ♦ Cursory radiological data transmitted during flight
 - Peak exposure rates

Helicopter

- ♦ Visual flight operation
- ♦ Detailed aerial surveys
 - Exposure rate contour maps
 - Dominant isotope gamma spectra
- ♦ Data analysis available 1-3 hours after flight completion

CMRT Organization Chart*



CM Home Team



- Bridge Line Coordinators
- GIS Scientist
- Assessment Scientist
 - Position filled by scientists from the National Labs
 - RSL scientist to assist in-house
- NARAC Support Personnel
- pFRMAC Administrator
- Laboratory Analysis

CMHT Capabilities

- CMweb
 - Provides access to maps and data/model products
- RAMS database
 - Allows responders to report field data related to radiation in real time to CMHT
 - Houses all data generated by or received by FRMAC
- Bridge line
 - Monitored conference lines available 24/7 during an event
 - Provides state and local responders with access to assessment scientists and agencies such as EPA, NRC, CDC for guidance
- Laboratory Analysis
 - Primary contact for fixed radiological laboratories
 - Data review and quality control

Advisory Team

- Provides coordinated advice and recommendations on environment, food and health matters to the Federal, state, local and tribal governments.
- Representatives from:
 - EPA
 - CDC
 - FDA
 - USDA
 - Other Federal agencies as needed

CMRT I Capabilities

- Advance Party meeting
- 24-hour per day operations for up to 72 hours
- Limited monitoring, sampling, and in situ
- Assessment
- Health and Safety
- Geographic Information System (GIS)
- Secure communications
- Logistics planning

CMRT II Capabilities

- 24-hour per day operations for several weeks
- Augmented monitoring, sampling, and assessment
- Laboratory Analysis
 - Sample receipt
 - Prepare samples for transport to labs
- Training for additional responders

CMRT Augmentation Capabilities

- 24-hour per day operation for several weeks
- Enhanced field analytical capability and capacity
- Fly-Away mobile laboratory

FRMAC – Assessment

- Interpret radiological conditions and provide guidance to responsible government authorities.
 - **Predictive Model Maps** (exposure/dose rate, areal deposition or integrated exposure/dose)
 - **Monitoring/Sampling Maps** (measurements of exposure/dose rate, areal deposition or integrated exposure/dose)
 - **Assessed Data** (field measurements and/or sample analysis results)
 - **Calculation Analysis** (DRLs, estimated doses, radionuclide mix, resuspension factor, etc.)
- All radiological predictions and measurements are evaluated in terms of the PAGs.

Turbo FRMAC

Deposition Sample: Am-241

Inputs

Inputs

Team & Equipment

Date & Time

Location

Radionuclide Mixture

Radionuclide Mixture

Review the completed Radionuclide Mixture.

Radionuclide	Activity Concentra...
²⁴¹ Am	1.00

μCi

/

m²

Results

Results

Event-Level Comparisons

Total Effective Dose/PAG Comparison

Deposition DRL Comparison

Crop/Produce Ingestion DRL Comparison

Milk Ingestion DRL Comparison

Action Level Concentration Comparison

Sample-Level Results

Deposition DRLs

Exposure Rate DRLs

Total Effective Dose

Deposition DRLs

Promote Deposition DRL Values to Event-Level

More Mixture Properties...

Filter Options

Age Group: Adult

Organ: Whole Body

Commitment Period: 50 to 70 Year

Radionuclide	Early Phase	First Year	Second Year	Fifty Year	Worker
²⁴¹ Am	52.9	35.3	69.2	20.7	2.74E4


Edit...

Close

Generate Report...


Promote Deposition Sample Values to Event-Level...

Electronic FRMAC



- Emergency Response Organization
 - Unified Command
 - State / County EOC
 - Other Federal agencies

Data Tablets (MPCD)



Monitoring & Sampling

Objectives & Products

- Protect lives and property
- Monitor key infrastructures
- Validate data to support decision-making
- Direct monitoring measurements
- Sampling (field to hotline)
- Electronic Data collection

Field Monitoring Activities and Equipment



Field Sampling Equipment



FRMAC – Health & Safety


- Sample Hotline Area
 - Directional signs and areas marked.
 - Periodic contamination surveys conducted.
 - Monitoring to ensure doses are ALARA.
 - Area as “habitable” as possible (chairs, cooling/heating, etc.).
 - Co-located near personnel and equipment hotline (away from FRMAC and labs).



FRMAC – Laboratory Analysis

- Ensure laboratory analyses are performed to support decision making.
- Track samples from drop-off at the Hotline through completion of analyses and disposal.
- “Triage” samples and distribute to laboratories for analyses.
- Verify and validate analytical results.
- Provide rapid laboratory analyses to support decision making.

FRMAC Interactions



Description of Phases

- Early/emergency phase
 - Time of release until release has been controlled
- Intermediate phase
 - Begins after source release has been controlled and continues until protective actions are terminated.
- Late/recovery phase
 - Begins when recovery action designed to reduce radiation levels to acceptable levels for unrestricted use are commenced.

PAGs – Protective Action Guides

- PAG – “committed effective dose equivalent or committed dose equivalent to an individual organ or tissue that warrants protective action following a release of radionuclides”

	Worker	Early Phase	First Year	Second Year	50 Year
Total Effective Dose	1000 mRem	1000 mRem	2000 mRem	500 mRem	5000mRem
Exposure Period	8 hours	4 days (96 hours)	365 days	365 days	50 years

DRLs, AALs, MQOs

- Derived Response Levels (DRLs) are the levels of activity in a sample that if in individual is exposed to for an extended period of time would lead to a dose equivalent to the PAG.
- Analytical Action Levels (AALs) are the activity levels in a sample which are equivalent to the DRLs
- Measurement Quality Objectives (MQOs) are the performance or acceptance criteria provided to the laboratories.

MQOs – Measurement Quality Objectives

- What question are we trying to answer?
- Does a result exceed the AAL?
 - Uncertainty at the AAL is important
- Is a radionuclide present?
 - Detection limit is important
- Not practical to define both the uncertainty at the AAL and the required detection limit.

Default Critical Levels (L_C)

	Air ($\mu\text{Ci}/\text{m}^3$)	Food ($\mu\text{Ci}/\text{kg}_{\text{wet}}$)	Forage ($\mu\text{Ci}/\text{kg}_{\text{wet}}$)	Milk ($\mu\text{Ci}/\text{kg}_{\text{wet}}$)	ST Soil ($\mu\text{Ci}/\text{Sample}$)	LT Soil ($\mu\text{Ci}/\text{Sample}$)	Water ($\mu\text{Ci}/\text{L}$)	Drinking Water ($\mu\text{Ci}/\text{L}$)
DRL TYPE APPLIED	Dp_DRL "Short Term"	DIL	Milk_DRL _{mass}	DIL	Dp_DRL "Short Term"	Dp_DRL "Long Term"	Milk_DRL _{water}	EPA guidelines
Am-241	3.54E-06	5.40E-06	7.20E-02	5.40E-06	3.54E-02	1.00E-03	6.00E-02	Contact FRMAC Assessment for appropriate value
Ba-140	1.79E-05	1.90E-02	7.90E-01	1.90E-02	1.79E-01	1.10E-02	6.60E-01	
Ce-141	2.39E-04	1.90E-02	1.30E+01	1.90E-02	2.39E+00	1.80E-01	1.10E+01	
Ce-144	1.90E-05	1.40E-03	9.40E-01	1.40E-03	1.90E-01	1.30E-02	7.80E-01	
Cf-252	3.73E-06	1.00E-05	1.30E-01	1.00E-05	3.73E-02	1.90E-03	1.10E-01	
Cm-242	7.03E-05	5.10E-05	5.10E-02	5.10E-05	7.03E-01	7.10E-04	4.30E-02	
Cm-244	6.22E-06	5.40E-06	5.40E-03	5.40E-06	6.22E-02	7.50E-05	4.50E-03	
Co-60	1.06E-06	2.00E-03	1.30E-01	2.00E-03	1.06E-02	1.90E-03	1.10E-01	
Cs-134	1.81E-06	2.50E-03	6.30E-03	2.50E-03	1.81E-02	8.80E-05	5.30E-03	
Cs-137	4.20E-06	3.70E-03	9.40E-03	3.70E-03	4.20E-02	1.30E-04	7.80E-03	

Field Measurements vs. Laboratory Analyses

- Rapid determinations
- Non-specific (portable survey meters)
 - Unable to identify alpha-emitters and pure betas
- Specific (In-situ gamma spec)
- Large uncertainties
- Not suitable for complex mixtures
- Longer turn-around times
- Positive identification of radionuclides including alpha- and beta-emitters
- Smaller uncertainties
- Suitable for complex mixtures

DOE Fly-away Laboratory

- High Purity Germanium Detectors
- Radon Compensating Alpha/Beta Counters
- Portable Liquid Scintillation Counters



Additional Equipment



Glove Box



Acknowledgements

- Sonoya Shanks
- Alan Remick
- Colleen O'Laughlin