

Post-Shot Radiation Environment in the National Ignition Facility

H. Khater, S. Brereton, L. Dauffy, J. Hall, L. Hansen, S. Kim, B. Pohl, S. Sitaraman, J. Verbeke

August 14, 2012

12th International Conference on Radiation Shielding Nara, Japan September 2, 2012 through September 7, 2012

Disclaimer

This document was prepared as an account of work sponsored by an agency of the United States government. Neither the United States government nor Lawrence Livermore National Security, LLC, nor any of their employees makes any warranty, expressed or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States government or Lawrence Livermore National Security, LLC. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States government or Lawrence Livermore National Security, LLC, and shall not be used for advertising or product endorsement purposes.



Post-Shot Radiation Environment in the National Ignition Facility

Presentation to

12th International Conference on Radiation Shielding

Nara, Japan September 5, 2012

Hesham Khater, Sandra Brereton, Lucile Dauffy, James Hall, Luisa Hansen, Soon Kim, Bert Pohl, Shiva Sitaraman, and Jerome Verbeke



Outline

- I. The NIF facility modeling
- II. Development of planning tools for estimating radiation exposure
- III. Results of activation analysis
- IV. Gamma spectrometry
- V. Worker dose management




Introduction

- A detailed 3-D model of NIF Target Bay (TB) has been developed
- An automated mechanism has been developed to allow for simultaneous analysis of contribution from all activated structures inside the TB
 - AAMI (Automated ALARA-MCNP Interface) is a coupling scheme between radiation transport and neutron activation codes
 - NEET (NIF Exposure Estimation Tool) is a web application that combines the information computed by AAMI with a given shot schedule to compute and display dose rate maps as a function of time
- Work planners can use NEET to estimate individual worker dose based on time required for a specific activity and for a specific location
- Estimated dose rate values are verified through the use of gamma spectrometry and passive dosimeters





NIF layout






NIF Target Bay Model








TB model: close-up sectional view







Features of the MCNP Target Bay model

- Structures including the floors, walls, support columns, braces, guard railing, and maintenance platforms
- Target Chamber with 120 diagnostic ports and 24 direct-drive ports
- Forty eight Final Optics Assemblies (FOAs)
- Target positioners (Cryo TARPOS and TARPOS) in the extended and retracted positions
- Target Alignment System (TASPOS)
- Three Diagnostic Instrument Manipulators (DIMs) in the extended and retracted positions
- X-ray diagnostics instruments:
 Dante and FFLEX
- Magnetic Recoil Spectrometer (MRS)










Methodology used by AAMI to estimate dose rates

- AAMI automates the dose rate calculations by conducting the following three steps:
 - Step 1: Neutron transport calculation using the MCNP 3D model and FENDL-2.1 data library to obtain 175-group flux spectra in each component of interest
 - <u>Step 2</u>: Activation analysis of components using the activation code, ALARA, to compute the γ-ray intensities and spectra for each cell and for several different cooling times after a shot
 - Step 3: γ-rays computed in the second step are sampled and emitted from each activated component, and propagated by a transport simulation through the entire MCNP model of the Target Bay






Methodology used by AAMI to estimate dose rates (Cont.)

- Gamma transport performed with user provided source subroutine for MCNP
- Volume-based sampling used with weight adjustment to correct bias for source strength
- γ-ray fluxes are tallied using a fine 3-D grid over the entire Target Bay, and are converted into dose rates using the ICRP-74 anterior-posterior effective fluence to dose conversion coefficients
- 3-D dose rate maps for different cooling times are stored in a database




AAMI flow chart






MCNP model of the Target Chamber during a shot






Dose rate map at Target Chamber equatorial plane following a 20MJ/7.1x10¹⁸ shot (5 days cooling)






Dose rate map at Target Chamber equatorial plane following a 20MJ/7.1x10¹⁸ shot (7 days cooling)






Dose rate map on platform above Target Chamber following a 20MJ/7.1x10¹⁸ shot (5 days cooling)





Dose rate map on platform above Target Chamber following a 20MJ/7.1x10¹⁸ shot (7 days cooling)





Dominant contributors to dose inside the Target Bay

- Large number of aluminum and stainless steel components are activated and the principal contributors are:
- Short term

$$\checkmark$$
 ²⁸AI (T_{1/2} = 2.2 m; < γ > = 1.78 MeV)
 \checkmark ²⁷Mg (T_{1/2} = 9.5 m; < γ > = 0.9 MeV)

Intermediate term


$$\sqrt{56}$$
Mn (T_{1/2} = 2.6 h; <γ> = 1.7 MeV)
 $\sqrt{24}$ Na (T_{1/2} = 14.7 h; <γ> = 4.1 MeV)

Long term

$$\checkmark$$
 58Co (T_{1/2} = 70.9 d; <γ> = 0.8 MeV)
 \checkmark 54Mn (T_{1/2} = 312.2 d; <γ> = 0.8 MeV)



Dose rates near polar DIM after 10¹⁵ shot




Dose rate at 1' from tip of the snout:

- 4 μSv/h after 6 h
- 3 μSv/h after 12 h
- 1.7 μSv/h after 1 day




Gamma spectrometry

- Spectrum obtained on a DIM snout 12 hours following 4.3x10¹⁴ shot
- Measured snout dose rates are typically between 0.03 and 0.15 mSv/h on contact when they are removed 4 hours after a 5x10¹⁴ shot
- Gamma spec readings of Target Bay and Target Chamber diagnostic components show primarily ²⁴Na and ⁵⁶Mn activities






NEET is a web-based application






Dose rates following a set of 10¹⁶ shots



Radiation environment is dominated by short-lived isotopes



NEET is used to develop annual ALARA Plan





Summary

- A detailed model of the TB has been developed to characterize the radiation environment within the TB following different categories of shots
- A set of computational tools was developed to help in estimating potential radiation exposure to workers from activated materials inside the Target Bay
- The Automated ALARA-MCNP Interface (AAMI) provides an efficient, automated mechanism to perform the series of calculations required to create dose rate maps for the entire facility
- The NIF Exposure Estimation Tool (NEET) is a web-based application that combines the information computed by AAMI with a given shot schedule to compute and display dose rate maps as a function of time
- Components close to TCC during a shot, like parts of the CryoTARPOS, TARPOS and the 3 DIMs represent a major source of gamma decay after being retracted outside the TC



Summary (cont.)

- Seven days following a 20 MJ shot, the dose rates in the immediate vicinity of the retracted components drop to < 0.2 mSv/h and the general ambient dose rate near the TC drops to < 0.01 mSv/h
- Primary NIF components, including the Target Chamber,
 Diagnostics and Beam Line Components, are constructed of aluminum
- Near-term Target Bay accessibility is driven by the decay of the aluminum activation product ²⁴Na
- NEET results are used to develop annual ALARA Plan
- Worker doses are tracked and managed using Sentinel software

