



LAWRENCE
LIVERMORE
NATIONAL
LABORATORY

Producing High Energy ns Pump Beams for Raman Amplification of Short Pulses using SBS Beam Combination

R. K. Kirkwood, R. A. London, P. Michel, D. Turnbull, J.
Moody, L. Divol, K. Fournier, W. Dunlop

July 23, 2013

Producing High Energy ns Pump Beams for Raman
Amplification of Short Pulses by SBS Beam Combination
Livermore , CA, United States
July 18, 2013 through July 18, 2013

Disclaimer

This document was prepared as an account of work sponsored by an agency of the United States government. Neither the United States government nor Lawrence Livermore National Security, LLC, nor any of their employees makes any warranty, expressed or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States government or Lawrence Livermore National Security, LLC. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States government or Lawrence Livermore National Security, LLC, and shall not be used for advertising or product endorsement purposes.



Producing High Energy ns Pump Beams for Raman Amplification of Short Pulses using SBS Beam Combination

**R. Kirkwood, R. London, P. Michel, D. Turnbull,
J. Moody, L. Divol, K. Fournier, W. Dunlop**

LLNL

Presentation at IZEST


Livermore Ca. July 18, 2013

Lawrence Livermore National Laboratory • National Ignition Facility & Photon Science

This work performed under the auspices of the U.S. Department of Energy by Lawrence Livermore National Laboratory under Contract DE-AC52-07NA27344

Plasma Amplification can allow pulse compressors to access the energy in many beams at NIF or other lasers

Concept for producing high energy short pulse at NIF




Depletion of a 1 ns pump beam by a ps seed will require 15 cm of plasma for interaction

- > to avoid absorption the plasma must be hot and low density (high kL_D)
- > strong linear damping of Langmuir waves at high kL_D requires high intensity

An attractive concept is a single collimated high intensity pump/heater of ns duration that is well collimated and intense through out the interaction region. This will naturally create a uniform density plasma in a gas that is heated to high temperature.

Such a pump can be produced via ion wave amplification/combination in a second plasma

Low absorption, and moderate density leads to strong damping in the Raman amplifier *requiring high pump intensity*



Limiting absorption and avoiding wave breaking push the Raman amplifier to high kL_D plasmas where significant pump intensity is needed to drive waves.

The conditions identified for 1 micron beams were studied at Jupiter in '09 where

- 1) 77x amplification of a weak seed was demonstrated [1,2].
- 2) Wave saturation effects were found to be described by 2D VPIC [2,3].


Further development of the Raman amplifier section is TBD [4].

The physics needed to combine ns pump beams by SBS has been demonstrated by the ignition program


The beam propagation in the beam crossing region of the ignition target demonstrates beam amplification.

Note:

One beam's intensity is increased 6x and overall energy is increased 2x with energy from the other beams when the beams wavelength are tuned near resonance.



incident laser beams in four ring cones



D. E. Hinkel LLNL



J. D. Moody et al.,
Nature Physics
(2012)

Ion wave amplification is already used to control the symmetry of the ignition target implosion



X-ray images of a converged capsule show the effect of the amplification of the beams at the waist, which squeeze it into a 'pancake' when their wavelength is tuned.

The observed capsule symmetry is seen to track the expected value when ion wave amplification is accounted for.




This 'wavelength tuning' is now the primary means of controlling drive symmetry in the ignition targets and has been necessary for demonstrating good implosion symmetry.

To bring the measured symmetry into agreement with models a saturation of the ion wave amplitude $\sim dn/n = 4.4 \times 10^{-4}$ has been invoked, and new models developed.

Saturation can have an effect on power transfer!



Nova: amplification of a single beam in a gas target plasma is controlled by its wavelength




A gas-filled bag created a uniform 2.6 mm diameter plasma with conditions allowing a 2.8 x amplification of a seed beam that transferred 1 kJ (40%) of the pump beams energy at Nova.

The amplification was controlled by the seed Wavelength.


The amplified beam had the same (or better) collimation than the incident beam.



Omega experiments in 2002-5 showed saturation that motivated present NIF models



[R. Kirkwood et al. PRL 2002 and PoP 2005]





Omega experiments use same frequency pump and seed beams with Mach = +1 flow in plasma to match resonance on one side of a CH or Al exploding foil.

Observed amplification was as much as 4x when the probe beam intensity was weak.

Amplification was observed to reduce with probe intensity, **also indicating saturation**.

Jupiter Experiments have also shown good focal quality is maintained in the absence of pump filamentation




[Y. Ping et al. PoP 2009]

Experiments at Jupiter have also shown that when the average intensity of a phase plate smoothed pump beam is below 4% of the filamentation threshold intensity, the angular structure of the incident beam, and its focal quality is best preserved.

-> We will keep pumps below this limit in the beam combiner to maximize focal quality.

A NIF target is designed to maximize energy transfer to a single beam with the properties needed for a pump

- To maximize single beam energy we:
 - have designed a target to initially produce plasma conditions similar to the beam crossing region of the ignition target but with longer interaction length (to reduce the effect of saturation) and minimal absorption or defocusing of the beam.
 - Have maximized energy transferred to a single high quality beam by separately shifting its frequency from that of the other crossing pump beams.
 - Will verify the energy and focal quality of the amplified beam by bringing it to focus on a witness foil during and initial test.
- A target that efficiently combines six NIF quads into a single 3-4 x amplified beam will enable designs of a 2nd stage Raman amplifier.
- Benchmarking models of power transfer and its saturation will provide confidence in future designs with still larger energies and larger numbers of combined beams.



The current 3-color tuning set-up at NIF can bring 5 pumps to resonance to amplify one beam in a uniform plasma

5 Pumps quads in a small angle Cone will have their frequency shifted to ion wave resonance:

$$\begin{aligned}\omega_{\text{pump}} - \omega_{\text{primary}} \\ \Delta\omega &= C_s |k_{\text{pump}} - k_{\text{primary}}| \\ &= C_s (2 k_o \sin(\theta_c/2))\end{aligned}$$


For $a < 2.5$ keV, $n/n_{\text{critical}} = 2.5\%$ critical plasma, the wavelength Shifts relative to the primary Beam for the 6 pumps are:

$$\begin{aligned}\Delta\omega_{\text{outer}} &< 0.21 \text{ nm} (0.63 \text{ nm @ } 1\omega) \\ \Delta\omega_{\text{inner}} &< 0.22 \text{ nm} (0.66 \text{ nm @ } 1\omega)\end{aligned}$$

NIF has this tuning capability

10 additional quads at large angle will pre-heat the gas filled target


With a uniform plasma 6 quads can be combined into a single beam!



Hydra simulations with optimized pointing show the needed plasma conditions are formed by 1.0 ns


Hydra shows additional absorption in wings of profile

Electron density is 2.5 % crit
And uniform




density

Electron temperature is 1.6 to 1.8 keV entire Interaction region



temperature




Note: heaters make T_e Uniform AND pre-heat skin


Hydra simulations with optimized pointing show the conditions are maintained to 2.0 ns

Hydra shows additional absorption in wings of profile


Electron density is 2.5 % crit
And uniform



Electron temperature is 1.7 to 1.9 keV in entire Interaction region



temperature




Pump beam absorption is less than 24% at 2.0 ns


Hydra shows additional
~<14% absorption in wings of profile
-> 40 kJ transmission possible

Total pump beam
Absorption due to
I.B. is <~ 24%

Electron density is 2.5 % crit
And uniform




Electron temperature
is 1.7 to 1.9 keV in entire
Interaction region




Flows are also minimal up to 2.0 ns allowing pumps to be resonant over the whole volume


Electron density is 2.5 % crit
And uniform



Ion wave aligned flow
Velocities are < 3
cm/microsecond
($< 0.08 M$) throughout
Interaction volume




Adding a fraction of H to He will produce ion wave damping rates of 0.1 to 0.2 in a cryo target



Combiner target conditions:
 $\text{Im}(w_{\text{iaw}})/\text{Re}(w_{\text{iaw}}) \sim 0.15 \text{ to } 0.3$

Hydra contours for I.A.W. frequency
 $= [0.9, 1, 1.1] \times (w_1 - w_2)$




Ignition studies indicate with 33% partial pressure of H_2 in He gas the ion wave damping rate should be $>10\%$ of the ion wave frequency, so that the entire beam crossing volume can be within the resonance width.

Target can also be tested at room temperature with C_5H_{12} gas (with greater absorption).

Project Name: *Beam Combination Demonstration*


Diagnostic Configuration

Diagnostics required:




Experimental set-up: One for each unique illumination AND diag config, e.g. if you change either, requires a different setup
 Priority: (1: must have, 2: like to have, 3: ride-along) Type: (1: New diag, 2: major mod, 3: minor mod or existing)

Experiment Layout - Target Chamber (Top View)




Diagnostic	Location	Pri.	Type	Calib
GXD	DIM 90-315	1	3	Pre-shot
DANTE-1	143, 274	1	3	Pre-shot
GXD	DIM 0,0	1	3	Pre-shot
FFLEX	90, 110	2	3	Pre-shot
FABS/NBI	Q31B	1	3	Pre-shot
SXI [L,U] (1,2)	161,326 18, 124	2	3	Pre-shot
DANTE-2	64, 350	2	3	Pre-shot

A GXD at the top of the chamber will image focal spot brightness and quality vs. time



The NIF SXI and a GXD in a standard location (90/315) will image pump beam brightness and time history



Conclusions



- A 5 quad SBS combiner has been designed to produce ~ 40 kJ of energy in a single NIF beam and can provide a high energy, collimated ns duration beam attractive for driving a $\sim <$ ps pulse Raman amplifier in a second stage.
- The physics and conditions of the beam combiner are very similar to the ignition target which produces up to 2x beam amplification regularly and reproducibly.
- Successful demonstration of a single beam combiner at NIF will increase the confidence in the design of multi – 100 kJ plasma amplifiers/compressors for large laser facilities.
- .

NIF

