



LAWRENCE
LIVERMORE
NATIONAL
LABORATORY

Direct Absorptivity Measurements of Metallic Powders Under 1-Micron Wavelength Laser Light

S. Wu, I. Golosker, M. LeBlanc, S. Mitchell, A.
Rubenchik, J. Stanley, G. Gallegos

July 31, 2014

25th Annual International Solid Freeform Fabrication
Symposium
Austin, TX, United States
August 4, 2014 through August 6, 2014

Disclaimer

This document was prepared as an account of work sponsored by an agency of the United States government. Neither the United States government nor Lawrence Livermore National Security, LLC, nor any of their employees makes any warranty, expressed or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States government or Lawrence Livermore National Security, LLC. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States government or Lawrence Livermore National Security, LLC, and shall not be used for advertising or product endorsement purposes.

Direct Absorptivity Measurements of Metallic Powders Under 1-Micron Wavelength Laser Light

*S. Wu, I. Golosker, M. LeBlanc, S. Mitchell,
A. Rubenchik, J. Stanley, G. Gallegos*

25th SFF SYMPOSIUM
Austin, TX, August 2014

 Lawrence Livermore
National Laboratory

This work was performed under the auspices of the U.S. Department of Energy by Lawrence Livermore National Laboratory under contract DE-AC52-07NA27344. Lawrence Livermore National Security, LLC



Abstract

- We report on absorption measurements of stainless steel powders illuminated by 1-micron light. Modeling of laser interaction with powders for various applications requires knowledge of absorption coefficients for commercially available materials and powder distributions. A simple method is developed for the direct calorimetric absorptivity measurements. Samples with thin layer of powder on thin Ta foil are uniformly irradiated using a diode-array laser emitting at 975 nm. Small thicknesses provide temperature uniformity across the sample. Temperature is monitored by thermocouples and IR camera. A scheme removing the effect of convective and radiative losses is implemented. Results for several layer thicknesses are presented.


Laser radiation absorption is an important part of the complex physics of additive manufacturing process

Needed:

- Adequate absorption description is required for comprehensive process modeling.
- Models of effective media are not applicable.


Approach:

- We have used direct absorptivity measurements, taking into account thermal losses and temperature-dependent material properties



This is the first direct absorptivity measurement of powders under laser light

Existent measurement scheme is expensive and doesn't work at elevated temperatures




Freeman, R. K., Rigby, F. A., and Morley, N. "Temperature-Dependent Reflectance of Plated Metals and Composite Materials Under Laser Irradiation," *J. of Thermophysics and Heat Transfer* **14**, 3, 2000.


U.S. Air Force Research Laboratory reflectometer

- Does not work well at elevated temperatures
- Difficulty in isolating thermal radiation
- Complex and expensive to implement

Scheme and Idea



Few thermocouples data showing nearly equal temperatures



1. Diodes can provide uniform irradiation over sample
2. At low intensity, thermal diffusion quickly equilibrates temperatures across the thin samples

Powder absorptivity

- Absorptivity can be found from the relation

$$\left(\rho_1 c_1 d_1 + \rho_2 c_2 d_2 \right) \frac{dT}{dt} = A(T)I - Q(T)$$

powder

substrate


thermal losses
(convective & radiative)

ρ – density
 c – specific heat
 d – thickness


- Measurement during the cooling provides the info about losses. Given the temperature dependent material parameters, we can determine the temperature-dependent absorptivity by analyzing temperature data in the heating and cooling periods.
- We will be able to apply the same method to powders of different material and composition, and at temperatures up to their melting points and above.

Prior experiments demonstrate uniform sample irradiation from diodes


Diodes light pattern



Few thermocouples data showing nearly equal temperatures. Data for 5 thermocouples in different point merges on the graph.




We are able to eliminate the thermal losses effect



Absorption data before (left) and after (right) removal of thermal losses

Prior absorptivity measurements on metals

6061 aluminum




Measurements were done on industrial grade samples.

Cold roll Al samples have a directional grooves resulting in polarization dependence.

We developed a special numerical procedure Improving the accuracy of data processing


6-4 titanium





Results summary

Metal absorptivity	0.8 μm	1 μm
Al	0.35	0.2
Ti	0.5	0.5

Experiment setup





3 VCSEL arrays
produce a 1 cm
diameter laser spot




Thermocouple sensors gives absorptivity
of sample under irradiation

Experiment demonstrates temperature uniform over the sample




Measured $A(T)$ of stainless steel powder








Absorption data for a 2-layer SS-316 powder sample

The results are consistent with ray tracing calculations of absorptivity


- Beam absorptivity was calculated along center strip




- Maximum absorption by spheres occurs without visible 'holes' in powder
- Minimum absorption by spheres occurs when hole allows beam to reach substrate



Scheme and Idea




Few thermocouples data showing nearly equal temperatures




1. Diodes can provide uniform irradiation over sample
2. At low intensity, thermal diffusion quickly equilibrates temperatures across the thin samples

The temperature measurements with thermocouples and IR camera helps calibrate IR camera output.(previous results)

Temperature evolution measured by thermocouple T_{tc} and IR camera T_c . FLIR calibration was used.



Ratio of T_{tc}/T_c is function of T_{tc} only, for three samples of Al



T_{tc}/T_c ratio measured on heating and cooling branches are identical and independent of pump intensity and heating rate. The emissivity is temperature dependent.

Conclusions

- **We suggested the new method for direct measurements of the powder absorptivity for different temperatures.**
- **The absorptivity can be measured for powders of different metals, composition, and thicknesses.**
- **We developed the method to eliminate the effect of thermal losses**
- **First experimental data are consistent with ray tracing modeling.**