



LAWRENCE
LIVERMORE
NATIONAL
LABORATORY

GeGI overview for IAEA

M. Burks

July 13, 2015

Disclaimer

This document was prepared as an account of work sponsored by an agency of the United States government. Neither the United States government nor Lawrence Livermore National Security, LLC, nor any of their employees makes any warranty, expressed or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States government or Lawrence Livermore National Security, LLC. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States government or Lawrence Livermore National Security, LLC, and shall not be used for advertising or product endorsement purposes.

This work performed under the auspices of the U.S. Department of Energy by Lawrence Livermore National Laboratory under Contract DE-AC52-07NA27344.

Annex 2: Preliminary information for proposed technology for the 2015 IAEA Technology Evaluation Workshop (TEW) on gamma imaging

1. Contact information

Morgan Burks
925-423-2798
burks5@llnl.gov

2. Product identification

Germanium Gamma-Ray Imager (GeGI) is a germanium based imaging system commercially available from PHDs Co.



3. Mobility

3.1. Size

30×15×23cm

3.2. Weight (With and without battery)

Instrument - 15 kg

Battery – 1 kg

3.3. Battery operation

Internal lead battery allows for ~45 minutes operation. Hot-swappable external LiPo batteries allow for 2-3 hours each.

3.4. Ruggedness, environment

Describe how the technology has been ruggedized for harsh environment(s).

4. Technology

4.1. Detector material

Germanium

4.2. Detection volume

1 cm thick x 8 cm diameter ~ 50cm³

Annex 2: Preliminary information for proposed technology for the 2015 IAEA Technology Evaluation Workshop (TEW) on gamma imaging

4.3. Number of pixels

Single segmented germanium crystal, readout using 32 channels.

4.4. Compton/Pinhole/Coded mask?

All three are supported. Removable tungsten pinhole and coded aperture.

5. Resolution

5.1. Angular resolution

Describe the spatial resolution or separation of sources in degrees.

5.2. Field of view:

Pinhole	60° Forward
Coded Aperture	~60° Forward
Compton	4 π

5.3. Energy range

Pinhole	40 - 500 keV
Coded Aperture	40 - 500 keV
Compton	150 - <3000 keV

5.4. Sensitivity ¹³⁷Cs

1 mCi source at 25 m (measured results)

Alarm: 3 minutes (3 sigma detection)

Identify: 8 minutes (8 sigma detection)

Localize: 14 minutes (3 sigma localization)

5.5. Sensitivity ⁵⁷Co

Not measured

5.6. Sensitivity RGPu / WGPu

GeGI has been used to image WGPu in many forms (shielded, unshielded, various shapes etc.) but specific sensitivity numbers are not available at this time.

5.7. Sensitivity NU / LEU / HEU

100 grams HEU, 98% enriched, at 28 m (measured results)

Identify: 15 minutes (8 sigma detection)


Localize: 39 minutes (3 sigma localization)

6. Graphical user interface (GUI)

6.1. Interface

The software offers an integrated environment for instrument control, data acquisition, and analysis. The spectrum window allows the user to interact with the spectrum similar to other commercial analysis software; the imaging panel provides an overlay of the optical camera and radiation measurement to assist in localizing the sources present.

Annex 2: Preliminary information for proposed technology for the 2015 IAEA Technology Evaluation Workshop (TEW) on gamma imaging



6.2. Processing software

Software has the following features for processing and analysing data

- Basic isotope identification
- Identification of "hot spots" in the image, identified by source ID
- Overlay of gamma-ray image with optical image
- Automated alarming

