

Determining thermochemical properties of halogenated metals: On enabling the rapid assessment of agent defeat formulations

J. M. Zaug, S. bastea, E. Stavrou, M. R. Armstrong, J. C. Crowhurst, H. B. Radousky

July 20, 2015

Disclaimer

This document was prepared as an account of work sponsored by an agency of the United States government. Neither the United States government nor Lawrence Livermore National Security, LLC, nor any of their employees makes any warranty, expressed or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States government or Lawrence Livermore National Security, LLC. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States government or Lawrence Livermore National Security, LLC, and shall not be used for advertising or product endorsement purposes.

This work performed under the auspices of the U.S. Department of Energy by Lawrence Livermore National Laboratory under Contract DE-AC52-07NA27344.

Determining thermochemical properties of halogenated metals: On enabling the rapid assessment of agent defeat formulations

- UNCLASSIFIED -

Pls: J. M. Zaug and S. Bastea Lawrence Livermore National Laboratory



Co-Pls:

E. Stavrou*, M. R. Armstrong*, J. C. Crowhurst, H. B. Radousky, Lawrence Livermore National Laboratory

* Significant year-four team effort/involvement

Basic Research Technical Review July, 2015

UNCLASSIFIED



Determining thermochemical properties of halogenated metals: On enabling the rapid assessment of agent defeat formulations

Pls: Joseph M. Zaug and Sorin Bastea - Lawrence Livermore National Laboratory BRCALL08-Per5-H-1-0052 (HDTRA-11-1-4538I)




Objective: Yr.-4 To determine the equations of state (EoS) of predicted biocidal agent products using x-ray diffraction (solid state: $MgCl_2$, TiF_4 , Hl_3O_8) and laser based shockwave and acoustic techniques (fluid state: $(C_2H_5)_3PO_4$ (TEP), Bil_3). To provide semi-empirical Cheetah Code guidance to large-scale field tests

Method: Synchrotron-based X-ray diffraction, ultrafast tabletop shockwave and time domain interferometery, photoacoustic light scattering based acoustics and semi-empirical thermochemical code developments (Cheetah V.7)

Status of effort: MgCl2 –EoS determined to 30+ GPa –Cheetah code parameterization completed; $(C_2H_5)_3PO_4$ shock Hugoniot measured and an EOS has been developed and implemented in Cheetah; Bil₃ EOS has been developed and implemented in Cheetah; TiF₄ XRD based EOS study in progress, Laser Repair completed March 2015

Personnel Supported:

Elissaios Stavrou (PD) began work, Sept. 2014 LLNL staff scientists: J. Zaug, S. Bastea, Mike Armstrong, Jonathan Crowhurst, and H. Radousky



Yr. # 1: AIF₃, AII₃, Ag₂O EOS development

<u>Yr. # 2</u>: MgF_2 , BF_3 , and I_2 , EOS development;

CHEETAH optimization tool development

Yr. # 3: MgCl₂, Bil₃ EOS begun, continued CHEETAH optimization tool development

Yr. # 4: MgCl₂, Bil₃, TEP, Hl₃O₈, completed, TiF₄ dev.


Funding: Year 1: FY12-\$224k, Year 2: FY13-\$228k, Year 3:

FY14-\$228k; Year 4: FY15-\$219K

PI contact Information:

Joe Zaug, <u>zaug1@llnl.gov</u> 925-423-4428 Sorin Bastea, <u>bastea2@llnl.gov</u> 925-422-2178





Program Objective



- Semi-empirically determine shock chemistry equilibrium states e.g., P, T, V, [product conc.] of halogen loaded explosive formulations
 - DTRA C-WMD mission success requires basic thermochemical knowledge of shock chemistry states – required to optimize energetic release of engineered biocides with minimal unintended dispersal
 - We elucidate extreme P-T condition halogen chemistry
 - Pursuit of our objective benefits energy sciences including efforts to enhance the efficiency of propulsion drive power plants

Background and Significance

- Halogen, interhalogen, and halogen oxide gases oxidize and disrupt the action of bacterial cells -membrane functionrelated genes are repressed
- In aqueous environments, halogens produce hypohalous acids, which if produced in high enough concentrations can stress a bacterium into activating virulence factor genes leading to secretions of endo- or exotoxins.
- Silver and lodine containing compounds are well-known biocidal agents
- Less selective agents could facilitate the antimicrobial action of a secondary agent nanoparticles (Amplify Toxicity*)


^{*} J. Kim, B. Pitts, P. S. Stewart, A. Camper, and J. Yoon, "Comparison of the antimicrobial effects of chlorine, silver ion, and tobramycin on biofilm", Antimicrobial Agents and Chemotherapy **52** 1446, (2008).


Background and Significance Preliminary Work

Our team developed and tested unique experimental and computational infrastructures (DOE and DOD developments)


- Backreflected and Photoacoustic Light Scattering (BR/PALS) sound speed, EoS characterization of fluids and mixtures (10's GPa, <1200 K)
- Ultrafast Shock Time Domain Interferometry (UTDI) 1 ns shockless or shock state characterizations
- CHEETAH-code v.7 EoS and interatomic potential library to predict detonation chemistry, (Typically <2% error in Detonation Performance Parameters)
- > 550 interagency U.S. government users


Technical Approach











Technical Approach - 1

Synchrotron X-ray Powder Diffraction - XRPD

- Static compression equations of state (EoS)
 - > Stringently developed EOS libraries interatomic interaction potentials to predict detonation chemistry
- V(P,T) EOS Data (T < 4-5 kK)
 XRPD is a well-accepted approach toward determining EOSs; materials structural information of general scientific importance; new molecules can be made characterized
 - > EOSs are determined rapidly, 2-3 days* e.g., surrogate agents, detonation products, polymers, HEs


^{*} After a sample is prepared

Technical Approach - 2

Ultrafast Time Domain Interferometry – UTDI

- Shock Hugoniot equations of state (EoS)
 - > Stringently developed EOS libraries interatomic interaction potentials to predict detonation chemistry
- Versatile High Data Throughput
 UTDI is a tabletop ultrafast dynamic compression instrument measures hydrodynamic properties of fluidand solid-state materials Compliments gas gun studies
 - > EOSs (once a sample is ready) are determined rapidly, 2-3 days e.g., surrogate agents, detonation products, polymers, HEs

Ultrafast Time Domain Interferometry (UTDI) is a Method to Characterize Dynamic Response Phenomena




UTDI + analysis examples: M.R. Armstrong et al. *JAP* <u>108</u>, 023511, (2010)

M.R. Armstrong et al. APL <u>92</u>, 101930, (2008)

UTDI is based on many other works

Tabletop Laser Based Shock Generation: A Small-Scale Experiment to Characterize Dynamic Properties



To enhance clarity, this drawing is not-to-scale

Technical Approach - 3




Cheetah-Code

- The Scientific Cheetah engine consists of highly predictive EoS of fluids and solids at high P-T, which are employed in the context of detonation theory to calculate the performance of energetic materials.
- Well-tested theories for multi-component-multi-phase systems underlie the physics and chemistry components of Cheetah, rather than empirical approaches such as Jones-Wilkins-Lee (JWL EoS)
- Cheetah is currently the most reliable non-experimental method for testing and surveying explosives related concepts –is routinely used by DOD and DOE customers to optimize material formulations
- Well-over \$ 1 B (2006 dollars) rigorously filtered (trusted) and incorporated experimental datasets

Cheetah is a highly predictive code

Cheetah performance for standard CHNO explosives (HMX, RDX, PETN, TNT, BTF, HNS, HNB, etc.)



Cheetah broad areas for improvement

- Halogenated (F and CI) compounds ionic dissociation needs to be explicitly modeled
- •Metal-loaded (e.g. Al, B, Si, W, Ti, P, etc.) formulations new products (e.g. HBO₂, B₂O₃, SiO₂, BCl₃), equations of state for solids/liquids (e.g. B₂O₃, BN), melting lines etc., need to be modeled
- Very high nitrogen compounds –
 formation of CN type polymers and/or solids likely needs to be accounted for
- High pressure and temperature explosive decomposition kinetics, metal oxidation kinetics, fluid phase chemical kinetics (particularly for expanded states), carbon kinetics
- Low gas detonations (e.g. thermites)
- •Liquids condensation (e.g. water, ammonia) for low (P, T) safety studies


- Materials EOS Advances -

- 1. MgCl₂ Finalized determination of the 300K P-V EOS up to 30 GPa; manuscript prepared for publication; results embedded into the Cheetah thermochemical code
- 2. (C₂H₅)₃PO₄, (TEP) UTDI measurements completed up to 18 GPa; unreacted Hugoniot results used to develop a TEP CHEETAH EOS; results sent directly to ARA personnel; manuscript prepared for journal submission
- 3. Bil₃ EOS developed (based on year-three PALS measurements) and embedded into the Cheetah code

- **4.** HI₃OI₈ Measured P-V EOS up to 30 GPa (XRPD); results used to develop a HI₃OI₈ CHEETAH EOS; results sent directly to AFRL/RWM personnel (B. Little made/provided the sample)
- 5. TiF₄ Measured preliminary P-V EOS up to 9 GPa (XRPD)
 - Diagnostic Advances -
- 6. Jaguar laser was refurbished for sound-speed measurements
- 7. ICP torch developed in our lab>enables chemical kinetics related to fire-ball induced chemistry>TRIR and 2-photon LIF diagnostics

Published a paper on the EOSs of AIF₃ and AII₃ E. Stavrou et al. *J. Chem. Phys.* <u>142</u>, 214506 (2015)


1. MgCl₂



2nd-order phase transition at 0.7 GPa > rhombohedral to hexagonal


Anisotropic lattice compression

> c-axis more compressible < 10 GPa




2. (C₂H₅)₃PO₄

200 shock data points, 50 shots per laser-drive energy Unreacted and reacted shock Hugoniot states observed Shock initiation threshold pressure (100 ps) is 15 GPa




3. Bil₃


Semi-empirical EOS established using DFT P-V results and our year-three PALS adiabatic sound-speed measurements



4. HI₃O₈


No structural phase transition < 50 GPa






5. TiF₄

No structural phase transition < 12 GPa Crystalline to amorphous PT at > 12 GPa





Coordination/Collaboration and Transition

- The development of a Cheetah-code Agent Defeat Toolbox (ADT) is an intensive and ongoing project
- Our template for success is the Joint Munitions Program –DOD munitions are continually optimized (user feedback and requests)
- Internal or external collaborative efforts (including Cheetah projects partially funded by other agencies) include, LLNL-NNSA Campaign-II High Explosives; LLNL-DHS LDRD DOD - Joint Munitions Program, TCGIII EOSs provided directly to AFRL/RWM and ARA personnel
- > 5-year transition ongoing approach with DOD/DTRA users
 Continue to provide accurate semi-empirical predictions and guidance to DOD and DTRA agent defeat munition efforts

Future Directions

- Finalize TiF₄ EOS study (a JMP leveraged effort); add to Cheetah-EOS library
- Start and complete Bil₃ P-V EOS study to test recent DFT predictions; improve/validate our existing EOS
- Start and complete BF₃ and SiF₄ sound-speed and/or P-V XRPD measurements; develop EOSs
- Submit the last National Lab DTRA/BAA sponsored project report; 13 EOSs; new thermochem. predictions

Continue to assist DTRA and provide HE agent defeat performance predictions in support of DTRA sponsored R&D and national defense initiatives